

ELECTRIC HOOK-UP INFORMATION SHEET

We have installed new 10 amp hook-up bollards across the park. This supply is designed for light use only. If you do lose your supply, there is a reset switch on the bollard.

SAFETY FIRST

Our hook-ups are via standard blue 240v IP44 electrical connectors protected by a Residual Current Device (RCD) for safety. They are designed to cut off the supply if there's a fault in your connecting lead, caravan or appliance.

- Your caravan or camping supply board must also have its own RCD.
- Use only approved cables. If you connect two cables together, the joining should be via approved connectors, covered against rain and supported off the ground.
- Domestic electrical appliances and units are not suitable for camping hook-ups and can be dangerous. Items meant for the home can draw more than 10 amps on their own, whereas caravan and camping appliances have special low wattage (see table on next page).
- Have your caravan or motorhome electrics regularly checked by a qualified electrician.
- Check that your electrical circuits are safe to use with a circuit tester available from most camping dealers.

HOW TO CONNECT

1. Make sure that the isolating switch in your unit is off
2. Connect your cables first to the unit
3. Then connect to the hook-up outlet and switch on
4. Run cables around the edge of the pitch away from vehicles or walkways

HOW TO DISCONNECT

When you are ready to leave:

1. Switch off your isolating switch
2. Disconnect the cable and remove
3. Make sure no cables are left lying around

BACK OF BEYOND ELECTRIC HOOK-UP INFORMATION SHEET

How to ensure light power usage

To avoid overloading the circuit breaker and losing supply, please ensure that all the equipment that you have switched on at any one time does not exceed 10 Amps.

The table below is only a guide. Each item of electrical equipment should have the wattage marked on it.

How to calculate amps

Watts ÷ 240 Volts = Amps

Camping appliances	Watts	Amps	Domestic appliances	Watts	Amps
Kettle	750	3.2	Kettle	2,200	9.2
Power supply/charger	125+	0.5-1			
Fan heater	1,000	4.4	Electric Heater	2,000-3,000	8.3-12.5
Television	70-150	0.6			
Travel hair dryer	600	2.6	Hair Dryer	2,200	9.2
Toaster	900	3.9	Toaster	1,500	6.3
Microwave	1,000	4.4	Microwave	2,000	8.3

Please note that we provide hair dryers in the Men's and Women's shower blocks.

Questions?

If you have any questions or encounter any difficulties, please call Reception on 01202 876968 or email info@backofbeyondtouringpark.co.uk